



NOTE: FREE THE FACE OF THE SHEATHING FROM SURFACE IRREGULARITIES THAT WOULD INTERFERE WITH A FLAT INTERFACE WITH THE TWF AND WINDOW, DOOR OR FIXTURE FLASHINGS. APPLY A COATING OF 650LT, CALIFORNIA SEALANT, GREEN CONCRETE LIQUID ADHESIVE, OR SHUR-TAC LIQUID ADHESIVE TO CLEAN AND DRY SURFACES THAT WILL BE RECEIVING THE FLASHINGS. BASE SELECTION OF LIQUID ADHESIVE ON THE SUBSTRATE AND VOC REQUIREMENTS. IN REVERSE SHINGLE APPLICATIONS OF THE TWF, WINDOW, DOOR, AND FIXTURE FLASHINGS, CLEAN THE SURFACE OF THE AIR BARRIER WITH A 30% SOLUTION OF ISOPROPYL ALCOHOL AND WATER.

ABS2.2

FRAMED BACKING WALL / SHELF ANGLE
(NOT TO SCALE)

© POLYGUARD PRODUCTS, INC. 2011

Polyguard

Polyguard Products, Inc.
P.O. Box 755 - Ennis, TX 75119
Phone: 214-515-5000 Fax: 972-875-9425
Web Site - www.polyguardproducts.com

MATERIALS SEPARATED FOR CLARITY

The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.