



TWF INSTALLATION SEQUENCE FOR A RISER:

1. INSTALL A POLYGUARD STAINLESS STEEL OR COPPER DRIP EDGE / DRIP COUNTER AND FITTINGS ALONG THE UPPER LEDGE EDGE.
2. FORM A CANT WITH LM-95 OR INSTALL A POLYGUARD TWF CANT ALONG THE RISER AND UPPER LEDGE WALL TO LEDGE INTERSECTION.
3. INSTALL POLYGUARD 300, 400, OR 400Z ALONG THE RISER AND WITH A MINIMUM 2" OVERLAP AT THE LOWER FLASHING TO THE HEIGHT OF THE UPPER LEDGE AND COVERING A MINIMUM 8" OF THE BACKING WALL AND TO WITHIN 5/8" OF THE FACE OF THE WALL.
4. INSTALL A POLYGUARD PREFORMED TWF OUTSIDE CORNER AT THE RISER TO UPPER LEDGE AND POLYGUARD 300, 400, OR 400Z TWF ADHERED TO A MINIMUM OF 8-INCHES OF THE RISER AND UPPER LEDGE BACKING WALLS AND 2-INCHES OF THE DRIP. TRIM THE FORWARD EDGE OF THE FLASHING BACK 5/8-INCH FROM THE EDGE OF THE RISER LEDGE AND BEND IN THE DRIP.
5. IN CAVITY WALL AND REVERSED SHINGLE APPLICATIONS INSTALL A POLYGUARD STAINLESS STEEL OR VINYL TERMINATION STRIP ALONG THE TOP EDGE OF THE FLASHING. IN NON-CAVITY WALL AND REVERSED SHINGLE APPLICATIONS INSTALL A POLYGUARD TERMINATION TAPE ALONG THE TOP EDGE OF THE FLASHING.
6. APPLY POLYGUARD DETAILING SEALANT ALONG THE OUTSIDE / TOP EDGE OF THE TERMINATION STRIPS AND ALONG END LAPS. TOOL THE SEALANT TO A UNIFORM AND EVEN COVERAGE.
7. INSTALL POLYGUARD HORIZONTAL WEEPS OVER THE FACE OF THE UPPER LEDGE FLASHING.
8. INSTALL THE VENEER.
9. TRIM THE WEEP EXTENSIONS FLUSH WITH THE FACE OF THE VENEER JOINT AFTER THE JOINT HAS BEEN TOOLED.

NOTE: FREE THE SURFACES THAT WILL RECEIVE THE FLASHING FROM IRREGULARITIES THAT WOULD INTERFERE WITH A FLAT INTERFACE WITH THE FLASHING, OR POSE A FLASHING PUNCTURE HAZARD. APPLY A COATING OF 650LT, CALIFORNIA SEALANT, GREEN CALIFORNIA SEALANT OR SHUR-TAC WATER-BASED LIQUID ADHESIVE TO CLEAN AND DRY SURFACES THAT WILL BE RECEIVING THE FLASHINGS. BASE SELECTION OF LIQUID ADHESIVE ON SUBSTRATE COMPATIBILITY AND VOC REQUIREMENTS. REFER TO POLYGUARDS PUBLICATION "PRINCIPLES OF WATERPROOFING ABOVE GRADE EXTERIOR WALL ASSEMBLIES" FOR STEP BY STEP INSTALLATION INSTRUCTIONS.

TWF 1.2

TWF VENEER RISERS

Polyguard Products, Inc.
P.O. Box 755 - Etnes, TX 75119
Phone: 214-515-5000 Fax: 972-875-9425
Web Site - www.polyguardproducts.com



© POLYGUARD PRODUCTS, INC. 2010
MATERIALS SEPARATED FOR CLARITY NTS

This literature is intended to assist in the selection and installation of Polyguard products. It is not intended to constitute a contract. The actual contract shall be the contract documents, specifications and conditions of sale, which apply to all goods supplied by us.