

## Installation Instructions

# DRIP EDGE, DRIP EDGE COUPLERS & DRIP EDGE PREFORMED CORNERS

**Drip Edges (Drip Edge)** and fittings are designed as a projecting flange for termination of the exterior edge of a **Through Wall Flashing (TWF)** membrane. The forward edge is sloped downward and functions as a drip.


The underside of the **Drip Edge** and associated fittings are available with a **Set 'N Seal™ 40mil Tape** that bonds the piece to the underlying surface.

The **Drip Edge** is designed for use with **TWFs** located above pedestrian traffic areas.


### Fittings:

**Drip Edge Couplers (Coupler)** are designed to join **Drip Edge** sections and **Drip Edge Preformed Corners** with **Drip Edge** sections. **Couplers** are only available with the **Set 'N Seal™ Tape**.

**Drip Edge Preformed Corners (Corner)** are designed to continue the **Drip** protection at inside and outside corners.



**Drip Edge Preformed Inside Corner Closed Hem Isometric View**



**Drip Edge Preformed Outside Corner Closed Hem Isometric View**

**Storage:** Protect the material from heat, crushing, moisture, mud, and construction dirt. Keep the product in the package until it will be used.

**Safety:** Material Safety Data Sheets are available upon request by phone, e-mail, or on the web.

### Installation Instructions

Applications without **Set 'N Seal™ Tape**:


Set the **Drip Edge** section into position on a supporting ledge with the bend along the drip aligned with the forward edge of the ledge. Maintain a 3/16-inch separation between **Drip Edge** sections and between **Corners** and **Drip Edge** sections. Join sections and preformed corners to sections by hooking the open hem of a **Coupler** onto the closed hems of the aligned pieces and removing the release paper to seal the **Coupler** onto the top side of the pieces. Apply pressure, over the top side of the **Coupler**, to complete the seal.

Applications with **Set 'N Seal™ Tape**:

Remove the protective release film from the **Tape** and set the **Drip Edge Section** into position on a supporting ledge with the bend along the drip aligned with the forward edge of the ledge. When the piece is in the aligned position, press along the top surface to adhere it to the undersurface. Maintain a 3/16-inch separation between **Drip Edge** sections and between **Corners** and **Drip Edge** sections. Join sections and preformed corners to sections by hooking the open hem of a **Coupler** onto the closed hems of the aligned pieces and removing the release paper to seal the **Coupler** onto the top side of the pieces. Apply pressure, over the top side of the **Coupler**, to complete the seal.

© Polyguard Products 2010


X:/Lit/Arch/Drip Edge, Drip Edge Couplers and Drip Edge Preformed Corners Installation Instructions.doc R.7-15-10



**Drip Edge Isometric View 1-1/2 and 3-inch Bed Depths**



**Drip Edge End View Closed Hem**



**Drip Edge Coupler Isometric View Open Hem**



**Drip Edge Coupler End View Open Hem**

P.O. Box 755  
Ennis, TX 75120  
PH: (214) 515-5000  
FX: (972) 875-9425

This information is based on our best knowledge, but POLYGUARD cannot guarantee the results to be obtained.

