
Installation Instructions

TERMINATION TAPE

Polyguard Termination Tape is designed to seal the top edge of any **Polyguard** flashing in a non-cavity wall assembly.

INSTALLATION

Storage: Protect the material from heat, crushing, moisture, mud, and construction dirt. Keep the product in the package until it will be used. For best results, the material should be stored between 50 to 75 degrees F prior to application.

Preparation: Prepare the surfaces where the **Termination Tape** will be attached so that, they are smooth relative to the construction surface, clean and dry.

Safety: Material Safety Data Sheets are available upon by phone, e-mail, or on the web.

Product Attachment: Test for adhesion. If the membrane can be separated from the

substrate without deforming the flashing, a liquid adhesive will be needed. In that event, apply a liquid adhesive, at a rate of 250-300 sq. ft. per gallon, to the surfaces that will receive the flashing. Use a liquid adhesive that is compatible with the substrates. Use solvent based **Polyguard 650LT**, (in California, **Polyguard California Sealant**) for substrates that are compatible with solvent based material and use water based **Polyguard Shur-Tac** for substrates that are not compatible with solvent based materials.

Installation: Remove the protective release paper backing and adhere the **Tape** to the substrate.

Apply pressure to the surface of the flashing with a rubber roller.

© Polyguard Products 2010

X:/Lit/Arch/Termination Tape Installation Instructions.doc R 6-24-10

P.O. Box 755
Ennis, TX 75120
PH: (214) 515-5000
FX: (972) 875-9425

This information is based on our best knowledge, but
POLYGUARD cannot guarantee the results to be obtained.

